


## 3 Listen to music



PLAY/PAUSE



下一曲



上一曲




The volume cannot be controlled with this product.

Please change the volume on the connected device.

## 4 Finish

Place the main units into the charging case to finish.



maxell

PA1443-00

maxell

# Quick Start Guide


Quick Start Guide

MXH-BTW1000




# 1

## Charging The Charging Case


### Charging



Charging of the charging case starts, indicator LED flashes. Charging is completed when the indicator LED turns off.




USB cable (included in package)





## Charging The Main Units

Place the main units into the charging case. The indicator LED on the main units turn red and charging starts.




Charging is completed when the indicator lights of the main units go OFF.




# 2

### Connecting



When the main units are removed from the charging case, the main units power on automatically, and the indicator LED starts flashing.




L  
Blue light and Red light flash alternatively.




R  
Blue light flashes slowly.




Activate Bluetooth on your Bluetooth device.



Please select "MXH-BTW1000" from the list displayed on your Bluetooth device.



When pairing is completed, the blue indicator LED flashes slowly.



### How to wear

Insert the pieces to ear ensure that the printed maxell logos are in a vertical orientation.



Turn the piece so that the logos are horizontal.

