

■ Instruction Manual

Thank you for purchasing this MAXELL product. Before use, make sure to read this Instruction Manual and use the product correctly and safely.

■ Introduction

About the user manual

- Contents of this user manual might be changed in the future without prior notice.
- For product improvement, change of appearance or specification might not be announced in advance.
- Except for personal use, any unauthorized copying of part or all parts of this manual is prohibited. Unauthorized republication is strictly prohibited.
- The names, logos and service marks are registered trademarks or trademarks of Maxell or other companies.

Disclaimer (Please refer to the warranty page for warranty details)

- Maxell shall not be responsible for any damage caused by fires, earthquakes, action of a third party, any accidents, intended or unintended misuse or other usage under abnormal conditions.
- All explicit and implicit contents not stated in the warranty card are not covered.
- Maxell shall not be responsible for failure due to any damage caused by usage other than described in the instruction manual.
- Maxell shall not be responsible for any loss resulted from malfunction when connecting to interconnecting devices.
- This product is not being designed to be any equipment or device which could be concerned with human life such as medical device, nuclear device, astronomic device, transportation device etc., nor equipment or devices which requires high reliability. In case this product is used for the above equipment and/or systems, Maxell do not responsible for any injuries or fire accident caused by the failure of this product.

■ Warning (safety precautions)

- Do not modify or disassemble the product, otherwise, fire, electric shock or failure may occur.
- Do not drop it, soak it in water, or heat it, otherwise, accident may occur.
- Do not place the product with the cable connected in an enclosed area such as a bag, pocket or bed etc.
- Do not store the product in places subject to high temperatures, such as in a car in hot weather or in direct sunlight.
- Do not handle the product with wet hands or use it around the water.
- Before connecting the product, check that there are no residues such as liquid, dirt or dust on the connector of the smartphone. Failure to do so may cause short circuit, overheating or fire.
- If you encounter any overheating, strange odours, or deformation while using this product, please immediately stop using it.
- Only use AA alkaline batteries. Furthermore, do not mix new and used batteries or different brands batteries. Doing so may cause leakage of batteries.
- If the product will not be used for a long time, remove the batteries and store it.
- Store it out of the reach of children so that they do not tamper with it.
- Do not use the product for purposes other than charging the compatible products.

■ Compatible models

The product is compatible to smartphone models that charge using USB Micro-B or USB type-C connector. ※The product cannot be used for models that charge using connectors of other shapes, or devices with a battery capacity equal to or higher than the tablet.

■ How to use

•How to charge your smartphone


- ① Connect the supplied cable to the main unit.
- ② Charging will start when the product is connected to the smartphone charging connector.

※It is not possible to charge a smartphone with a USB Micro-B connector and a smartphone with a USB Type-C connector at the same time.


※iPhone can be charged with a genuine Apple cable.

- ① Plugging the cable into the charger will reduce the battery level, so be sure to disconnect the cable after use.

For Micro-B Connector




For Type-C Connector



■ Battery replacement procedure

The product can be used repeatedly by replacing the batteries. If the LED indicator that indicate the energization state does not light even after connecting the supplied cable or genuine Apple cable, please replace the batteries according to the following procedure.



① Make sure that the cable is not connected. ② Slide the battery cover and remove it. ③ Remove the old batteries and insert new batteries. ④ Attach the battery cover.

Recommended batteries for device charging: **Maxell AA alkaline battery**

Maxell, Ltd.

30-13 Motoyoyogi-Cho, Shibuya-Ku, Tokyo 151-8527

<http://www.maxell.co.jp>

PA1721-00

※ When closing, insert the battery cover into the main unit until it clicks.

❶ When replacing batteries, use new AA alkaline batteries and replace all 6 batteries at the same time. ❷ Make sure the ⊕ and ⊖ terminals are oriented correctly when inserting the batteries.

■ Precautions for use

• It cannot be used if the power does not turn on at all even if pressed and holding the power button on the smartphone. • The supplied cable (Micro-B and Type-C) is designed exclusively, so be sure to use the supplied cables. Connecting with other cable may cause malfunction. • When connecting, be sure to check the orientation of the connector. If the orientation is correct, it will connect smoothly. Forcible connection may cause an accident or malfunction. • Be sure to hold the housing when connecting or disconnecting the connector. Pulling the cable may cause malfunction. • Do not use USB Micro-B and USB Type-C connectors that have been bent. The inside of the connector may be deformed, causing short circuit to overheat or cause fire. • Do not charge a device for more than 2 hours continuously. The smartphone battery may discharge and the power may not turn on. • Use the smartphone with the battery installed. • Do not use during system update. • If the smartphone's charge level does not increase after charging, please turn off the power and restart it. • Before using the product, please back up the memories, such as the phonebook, image data, music data. We shall not be liable for any incidental compensation for damages resulting from loss of various memory or loss of communication opportunity due to factors such as product failure or malfunction. Please note before use. • If the payment function (Osaifu-Keitai) becomes unusable, we shall not be able to take any responsibility. • The illustrations of the product and accessories described in "How to use" in this manual may differ slightly from the actual products. Thank you for your understanding.

■ Specifications

Main Unit

Dimensions: W63×H108×T18.4mm

Output(USB-A): DC5V / Max1A

Weight: Approx. 49g (excluding battery and cable)

Operating temperature range: 5~35°C

Storage temperature range: 0~40°C

Accessories

Charging Cable: USB-A — Micro-B+Type-C approx. 100cm

AA Alkaline battery: Maxell LR6(T)/1.5V