


maxell**V Line Trimmer
MXVT-100**

PA1658-00

* Do not wash

User manual

Thank you for purchasing this MAXELL product. Before use, make sure to read this Instruction Manual and use the product correctly and safely.

Contents of the package**1 Introduction****About the user manual**

- This Instruction Manual may be subject to change without prior notice.
- In order to improve the product, external appearance or part of the specifications may be subject to change without prior notice.
- Unauthorized duplication of part or all of this Instruction Manual without permission is prohibited except for the case of personal use. In addition, do not reprint this Instruction Manual without permission.

Disclaimer (See the warranty certificate for details of the warranty.)

- Maxell shall not be responsible for any damage caused by fires, earthquakes, action of a third party, any accidents, intended or unintended misuse or other usage under abnormal conditions.
- The warranty stated in the warranty certificate is all we warrant, and we do not warrant anything except for this warranty including express warranty and implied warranty.
- Maxell shall not be responsible for failure due to any damage caused by usage other than described in the instruction manual.

This product is not being designed to be any equipment or device which could be concerned with human life such as medical device, nuclear device, astronomical device, transportation device etc., nor equipment or devices which requires high reliability. In case this product is used for the above equipment and/ or systems, Maxell do not responsible for any injuries or fire accident cause by the failure of this product.

2 Safety Caution

Please strictly follow

	Danger	If it is handled incorrectly, the user may suffer death or severe injury*1 and the urgency is high.
	Warning	If it is handled incorrectly, it is assumed that the user may suffer death or serious injury*1.
	Caution	If it is handled incorrectly, it is assumed that the user may suffer minor injury*2 or there is a possibility that property damage*3 may occur.*

*1: Severe injury is indicated by those that have after effects such as blindness, injury, burns (high temperature burns/low temperature burns, chemical burns), electric shock, fracture, poisoning, etc. and those requiring hospitalization or long-term regular hospital visits for treatment.

*2: Minor injury refers to hurt, burnt, electric shock, etc. which do not result in hospitalization or long-term follow-up consultation.

*3: Property damage refers broad damages to houses or properties and domestic animals/pets.

⚠ Danger**Take power only from the USB port**

When charging, please use USB port of computer etc. or USB adapter.
Using other power exceeding USB rating may result in heat generation, ignition, malfunction, electric shock or injury.

⚠ Warning**Check for any deformation or damage before use or when attaching/ detaching the comb**

It may cause injury.

Do not share a product with multiple people, such as family members or others

Doing so may cause infection or inflammation.

The following people, please consult a doctor before use

Consult a doctor before use if you are a outpatient, have a medical condition, have a sensitive skin, are pregnant or suspect you have allergies. In addition, even if you do not meet the above category, if any abnormalities appear, stop using the product immediately and consult a doctor.

Do not use if you have a sunburn, skin problem (rough skin, blemish etc.) or injury

Symptoms may worsen.

Do not use the product in environments where it is exposed to liquids such as water

The main unit is not waterproof. Do not use it in water or in an environment where it may get wet. Doing so may cause overheating, electric shock, malfunction or injury.

Do not use the product with wet hands

It may cause overheating, electric shock, malfunction or injury.

Examples of Symbol		Stands for prohibited actions when handling the product. Graphic symbols representing specific instructions are shown in black colour in the shape of
		Stands for caution to fire, explosion, high temperature when handling the product. Graphic symbols representing specific instructions are shown in black colour in the shape of
		Stands for instruction which must be followed. Graphic symbols representing specific instructions are shown in white colour in the shape of

Do not touch leaked liquid

Please do not touch the leaked liquid. If liquid leaks from this device and gets into the eye, do not rub. Rinse with plenty of clean water immediately and consult a doctor. It may cause blindness.

Do not use for any purposes other than treating V line

It may cause injury or damage to the main unit.

Use and store it out of reach of children

It may cause injury or accident.

Do not use if there is an abnormality such as heat generation, discoloration, deformation or unusual smell during storage or use

It may cause fire, explosion, leakage or injury.

Charge and use within the temperature range of 10~35°C

Charging and using at temperatures outside this range may cause leakage, overheating, breakage, or malfunction.

If the charging is not completed within the predetermined charging time, please stop charging

It may cause leakage, overheating, fire or breakage.

Make sure that the AC adapter is fully inserted

If it is not fully inserted, it may cause an electric shock or a fire due to dust.

If an abnormality occurs during charging, immediately disconnect the AC adapter from the outlet

Failure to do so may cause smoke, fire, explosion or malfunction.

Do not repair, modify or disassemble these parts

Overheating, ignition, fire, breakage, leakage, malfunction, injury may occur.

Do not put into fire

This may result in ignition, heat, breakage.

⚠ Caution**Do not use shaving cream, cold cream or milky lotion**


It may cause clogging.

Do not use or store in humid environment such as bathrooms

Doing so may cause overheating, electric shock, malfunction, mold or rust.

Do not apply the comb to the skin during operation.

It may cause burn or injury.

3 Name of Each Part**Do not allow a strong impact by stepping on or dropping**

Deformation may cause liquid leakage, overheating, fire, explosion or malfunction.

Do not place combustible or heavy objects on, cover or wrap with blankets or cushions

It may cause overheating, fire, explosion or liquid leakage.

Do not place the product in cooking appliances such as microwave ovens or high-pressure containers

It may cause overheating, smoke or fire.

If not used for a long period of time, please charge the battery once every 3 months

Battery may deteriorates and cannot be used.

Do not use for pets

Pets may cause burns and injuries.

Do not apply excessive force

It may cause deformation, leakage, heat, ignition, breakage, failure.


4 Applicable Parts

V LINE		
I LINE		
O LINE		

5 Charging

This product has a built-in lithium ion battery. After purchase, please charge the battery before use.

1. Connect the included charging cable to the USB port of the main unit and your PC or AC adapter with USB terminal.
2. The red LED lights up and charging starts.
3. When the green LED lights up, charging is complete. (charging time: approx. 3 hours)
4. Remove the charging cable.




Caution

- Charging time is approximately 3 hours. (Charging time varies depending on the remaining battery capacity and charging environment.)
- Button operation is disabled during charging.
- When charging, set the slide switch to position 0 (OFF).
- Only use the included charging cable.
- Charge the battery in an environment of 10-35°C
- If not used for a long period, charge it once every 3 months. The battery may deteriorate and cannot be used.

6 How To Use

1. Insert the comb firmly into the comb slot.
2. Slide the slide switch to position 1 or 2 and the blue LED will flash.

	Level 1	Level 2
Temperature of heating wire	approx. 200°C	approx. 250°C



3. Pinching the hair lightly with your fingertips and move the part you want to trim to the comb.

※You can trim 10 to 15 strands of hair at a time.

4. Press the push button to turn on the blue LED and heat up the heating wire. The hair is burned off by the heat.
※For safety, when it is pressed and held for about 30 seconds it will stop automatically and the blue LED will flash. When it stops, press the push button again.
5. After use, set the slide switch to position 0 (OFF).
※The comb is hot after use. Please cool down for about 1 minute.

Caution

- The comb is very hot. Please do not apply directly to the skin. Doing so may cause burns.
- Remove the comb when carrying.
- Do not use when hair is wet. The temperature of the heating wire will drop, making it unable to trim the hair.
- When trimming, the hair burning smell will occur.

7 Maintenance

Before cleaning the product, make sure that the battery is not being charged and that the slide switch is set to position 0 (OFF).
The comb is hot after use. Please cool down for about 1 minute.

Maintenance of the main unit

- Wipe off dirt with a dry soft cloth. If it is heavily soiled, wipe it off with a cloth dampened with water.
- Please clean the comb according to "Maintenance of the comb".

Maintenance of the comb

- Use the brush provided to remove the hair inside the comb.

Replacing the comb

- Remove the comb on the main unit and insert a new comb firmly into the comb slot.

Caution

- This product is not waterproof. Do not wash.
- Do not wipe the main unit with benzene, thinner, alcohol, etc.

8 Troubleshooting (When problems arise)

Symptom	Cause	Solution
LED does not light On	Battery is empty	Please charge
Poor cutting performance	The comb or heating wire is damaged or deformed	Replacing the comb
	Hair or the comb is wet	Dry hair or comb
	Battery level is low	Please charge
Could not cut	The heating wire is broken	Replace the comb

9 Specification

Main Unit	Dimensions	W24×H155×D30mm (without comb)
	Weight	Approx. 55g
	Input voltage / current	DC 5V/ Max 400mA
	Built-in battery	Lithium ion battery 3.7V 700mAh
	Charging time	Approx. 3 hours
Charging Cable	Length	Approx. 60cm

10 Discard this product

⚠ Caution Disposal of rechargeable batteries in Japan



Li-ion 00

The built-in rechargeable battery can be recycled.

Do not remove the rechargeable battery yourself, please contact our Customer Service Center.

Please refer to the JBRC website for information on rechargeable battery collection / recycling and recycling partners.

Maxell, Ltd.

30-13 Motoyoyogi-Cho, Shibuya-Ku, Tokyo 151-8527

<http://www.maxell.co.jp>